

CAMERA Model Names -- and Associated LIST of RAW Image Names [[FileName.Extension](#)]

**Total of ~ 84 RAW Formats
in ALPHABETICAL ORDER**

Apple	(20)	Nikon	(94)
Canon	(118)	Nokia	(5)
Casio	(26)	Openlab	(1)
Contax	(1)	Olympus	(70)
DxO	(1)	OnePlus	(6)
Epson	(3)	Panasonic	(103)
Fujifilm	(77)	Parrot	(1)
Gimp	(1)	Pentax	(46)
Google	(15)	Phase One	(27)
GoPro	(4)	Photoshop - Adobe	(1)
Hasselblad	(33)	Ricoh	(15)
Huawei	(11)	Samsung	(46)
Kodak	(14)	Sigma	(7)
Konica Minolta	(11)	Skydio	(1)
Leaf	(22)	Sony	(87)
Leica	(43)	Yuneec	(2)
LG	(21)	Zeiss	(2)
Light	(1)		
Mamiya	(9)		

RAW .Extn

RAW .Extn

Apple

iPad Pro 9.7" (Wifi and Cellular)	DNG
iPad Pro 11-inch (2nd generation)	DNG
iPad Pro 11-inch (2018 model)	DNG
iPad Pro 12.9-inch (4th generation)	DNG
iPad Pro 12.9-inch (2018 model)	DNG
iPhone 6s	DNG
iPhone 6s Plus	DNG
iPhone 7	DNG
iPhone 7 Plus	DNG
iPhone 8	DNG
iPhone 8 Plus	DNG
iPhone SE (2020 version)	DNG
iPhone SE	DNG
iPhone X	DNG
iPhone XR	DNG
iPhone XS	DNG
iPhone XS Max	DNG
iPhone 11	DNG
iPhone 11 Pro	DNG
iPhone 11 Pro Max	DNG

Canon / contd

EOS 30D	CR2
EOS 40D	CR2
EOS 50D	CR2
EOS 60D	CR2
EOS 60Da	CR2
EOS 70D	CR2
EOS 77D (EOS 9000D)	CR2
EOS 80D	CR2
EOS 90D	CR3
EOS 200D	
(EOS Kiss X9, EOS Rebel SL2)	CR2
EOS 250D	
(EOS Rebel SL3, EOS 200D II,	
EOS Kiss X10)	CR3
EOS D30	CRW
EOS D60	CRW
EOS 300D	
(EOS Digital Rebel, EOS Kiss Digital)	CRW
EOS 100D	
(EOS Digital Rebel SL1, EOS Kiss X7)	CR2
EOS 500D	
(EOS Digital Rebel T1i,	
EOS Kiss X3 Digital)	CR2
EOS 550D	
(EOS Digital Rebel T2i,	
EOS Kiss X4 Digital)	CR2
EOS 1100D	
(EOS Digital Rebel T3,	
EOS Kiss X50 Digital)	CR2
EOS 600D	
(EOS Digital Rebel T3i,	
EOS Kiss X5 Digital)	CR2
EOS 650D	
(EOS Digital Rebel T4i,	
EOS Kiss X4i)	CR2
EOS 700D	
(EOS Digital Rebel T5i,	
EOS Kiss X7i)	CR2
EOS 1200D	
(EOS Digital Rebel T5,	
EOS Kiss X70)	CR2
EOS 1300D	
(EOS Digital Rebel T6,	
EOS Kiss X80)	CR2

Canon

EOS-1D	CRW
EOS-1D C	CR2
EOS-1D Mark II	CR2
EOS-1D Mark II N	CR2
EOS-1D Mark III	CR2
EOS-1D Mark IV	CR2
EOS-1Ds	CR2
EOS-1Ds Mark II	CR2
EOS-1Ds Mark III	CR2
EOS-1D X	CR2
EOS-1D X Mark II	CR2
EOS-1D X Mark III	CR3
EOS 5D	CR2
EOS 5D Mark II	CR2
EOS-5D Mark III	CR2
EOS-5D Mark IV	CR2
EOS 5DS	CR2
EOS 5DS R	CR2
EOS 6D	CR2
EOS 6D Mark II	CR2
EOS 7D	CR2
EOS 7D Mark II	CR2
EOS 10D	CRW
EOS 20D	CR2
EOS 20Da	CR2

	RAW .Extn		RAW .Extn
Canon / contd			
EOS 1500D		PowerShot G1 X	CR2
(EOS Rebel T7, EOS Kiss X90,		PowerShot G1 X Mark II	CR2
EOS 2000D)	CR2	PowerShot G1 X Mark III	CR2
EOS 3000D		PowerShot G2	CRW
(EOS Rebel T100,		PowerShot G3	CRW
EOS 4000D)	CR2	PowerShot G3 X	CR2
EOS 750D		PowerShot G5	CRW
(EOS Digital Rebel T6i,		PowerShot G5 X	CR2
EOS Kiss X8i)	CR2	PowerShot G5 X Mark II	CR3
EOS 760D		PowerShot G6	CRW
(EOS Digital Rebel T6s,		PowerShot G7 X	CR2
EOS Kiss 8000D)	CR2	PowerShot G7 X Mark II	CR2
EOS 800D		PowerShot G7 X Mark III	CR3
(EOS Digital Rebel T7i,		PowerShot G9	CR2
EOS Kiss X9i)	CR2	PowerShot G9X	CR2
EOS 850D		PowerShot G9 X Mark II	CR2
(EOS Kiss X10i, EOS Rebel T8i)	CR3	PowerShot G10	CR2
EOS 1000D		PowerShot G11	CR2
(EOS Digital Rebel XS, EOS Kiss F)	CR2	PowerShot G12	CR2
EOS 450D		PowerShot G15	CR2
(EOS Digital Rebel XSi,		PowerShot G16	CR2
EOS Kiss Digital X2)	CR2	PowerShot Pro 1	CRW
EOS 350D		PowerShot Pro70	CRW
(EOS Digital Rebel XT,		PowerShot Pro90 IS	CRW
EOS Kiss Digital N)	CR2,	PowerShot S30	CRW
	CRW	PowerShot S40	CRW
		PowerShot S45	CRW
EOS 400D		PowerShot S50	CRW
(EOS Digital Rebel XTi,		PowerShot S60	CRW
EOS Kiss Digital X)	CR2	PowerShot S90	CR2
EOS M	CR2	PowerShot S95	CR2
EOS M2	CR2	PowerShot S70	CRW
EOS M200	CR3	PowerShot S100	CR2
EOS M3	CR2	PowerShot S100V	CR2
EOS M5	CR2	PowerShot S110	CR2
EOS M6	CR2	PowerShot S120	CR2
EOS M6 Mark II	CR3	PowerShot SX1 IS	CR2
EOS M10	CR2	PowerShot SX50	CR2
EOS M50 (EOS Kiss M)	CR3	PowerShot SX60 HS	CR2
EOS M100	CR2	PowerShot SX70 HS	CR3
EOS R	CR3		
EOS R5	CR3		
EOS R6	CR3		
EOS Ra	CR3		
EOS RP	CR3		
PowerShot 600	CRW		
PowerShot A5	CRW		
PowerShot A50	CRW		
PowerShot G1	CRW		

Fujifilm /cntd

X-E3	RAF
X-H1	RAF
X-Pro1	RAF
X-Pro2	RAF
X-Pro3	RAF
X-S10	RAF
X-T1	RAF
X-T1 IR	RAF
X-T2	RAF
X-T3	RAF
X-T4	RAF
X-T10	RAF
X-T20	RAF
X-T30	RAF
X-T100	RAF
X-T200	RAF
XF1	RAF
XF10	RAF
XQ1	RAF
XQ2	RAF

Gimp

Native Image Format	XCF
---------------------	-----

Google

Pixel	DNG
Pixel XL	DNG
Pixel 2	DNG
Pixel 2 XL	DNG
Pixel 3	DNG
Pixel 3 Front Standard Camera	DNG
Pixel 3 Front Wide Camera	DNG
Pixel 3 XL	DNG
Pixel 3 XL Front Standard Camera	DNG
Pixel 3 XL Front Wide Camera	DNG
Pixel 4	DNG
Pixel 4 XL	DNG
Pixel 5 Front Camera	DNG
Pixel 5 Rear Main Camera	DNG
Pixel 5 Rear Ultra Wide Camera	DNG

GoPro

FUSION	GPR
HERO5 Black	GPR
HERO6 Black	GPR
HERO7 Black	DNG

RAW .Extn

Hasselblad

503CWD	3FR
A6D-100c	3FR
CF-22	3FR
CF-22MS	3FR
CF-39	3FR
CF-39MS	3FR
CFH-22	3FR
CFH-39	3FR
CFV	3FR
CFV-50c	3FR
H2D	DNG
H2D-22	3FR
H2D-39	3FR
H3D-22	3FR
H3D-39	3FR
H3DII-22	3FR
H3DII-31	3FR
H3DII-39	3FR
H3DII-39MS	3FR
H3DII-50	3FR
H4D-40	3FR
H4D-60	3FR
H5D-40	3FR
H5D-50	3FR
H5D-50c	3FR,
<i>H5D-50c</i>	<i>FFF</i>
H5D-60	3FR
H6D-100c	3FR
HV	ARW
Lunar	3FR
Stellar II	3FR
X1D	3FR
X1D II 50C	3FR

Huawei

Honor 20 Pro Rear Main Camera	DNG
Honor 20 Pro Rear Telephoto Camera	DNG
Honor 20 Pro Rear Wide Camera	DNG
Mate 10 Pro	DNG
P30 Rear Main Camera	DNG
P30 Rear Telephoto Camera	DNG
P30 Rear Wide Camera	DNG
P30 Pro Rear Main Camera	DNG
P30 Pro Rear Telephoto Camera	DNG
P30 Pro Rear Wide Camera	DNG
P9 Lite	DNG

RAW .Extn

Kodak

DCS 14n
DCS 720x
DCS 760
DCS Pro 14nx
DCS Pro SLR/n
EasyShare P712
EasyShare P850
EasyShare P880
EasyShare Z1015 IS
EasyShare Z980
EasyShare Z981
EasyShare Z990
Kodak Bitmap
Kodak RAW Image

RAW .Extn

DCR
DCR
DCR
DCR
DCR
DCR
KDC
KDC
KDC
KDC
RAW
RAW
FPX
KE2

Leaf

AFi II 6
AFi II 7
Aptus 17
Aptus 22
Aptus 54s
Aptus 65
Aptus 75
Aptus 75s
Aptus-II 5
Aptus-II 6
Aptus-II 7
Aptus-II 8
Aptus-II 10R
Aptus-II 12
Valeo 6
Valeo 11
Valeo 17
Valeo 22
Credo 40
Credo 50
Credo 60
Credo 80

RAW .Extn

MOS
MOS
MOS
MOS
MOS
MOS
MOS
MOS
MOS
MOS
MOS
MOS
MOS
MOS
MOS
MOS
MOS
MOS
MOS
MOS
IIQ
IIQ
IIQ
IIQ

Konica Minolta

Alpha-5 Digital (China)
Alpha Sweet Digital (Japan)
DiIMAGE 5
DiIMAGE 7
DiIMAGE 7i
DiIMAGE 7Hi
DiIMAGE A1
DiIMAGE A2
DiIMAGE A200
Maxxum 5D Dynax 5D
Maxxum 7D Dynax 7D

MRW
MRW
MRW
MRW
MRW
MRW
MRW
MRW
MRW
MRW
MRW

	RAW .Extn	RAW .Extn	RAW .Extn
<u>Leica</u>		<u>LG /contd</u>	
C (Typ 112)	RWL	G7 ThinQ	DNG
D-Lux 2	RAW	G8 ThinQ Front Camera	DNG
D-Lux 3	RAW	G8 ThinQ Rear Main Camera	DNG
D-Lux 4	RWL	G8 ThinQ Rear Wide Camera	DNG
D-Lux 5	RWL	V40 ThinQ Front Standard Camera	DNG
D-Lux 6	RWL	V40 ThinQ Rear Main Camera	DNG
D-Lux 7	RWL	V40 ThinQ Rear Wide Camera	DNG
D-Lux (Typ 109)	RWL	V50s ThinQ Front Camera	DNG
Digilux 2	RAW	V50s ThinQ Rear Main Camera	DNG
Digilux 3	RAW	V50s ThinQ Rear Wide Camera	DNG
Digital-Modul-R	DNG	V60 ThinQ Front Camera	DNG
M9	DNG	V60 ThinQ Rear Main Camera	DNG
M10	DNG	Velvet Front Camera	DNG
M10-D	DNG	Velvet Rear Main Camera	DNG
M10-P	DNG	Velvet Rear Wide Camera	DNG
M10-R	DNG	Wing Rear Main Camera	DNG
M (Typ 262)	DNG	Wing Front Camera	DNG
M-D (Typ 262)	DNG	Wing Rear Wide Camera	DNG
M-E	DNG		
M-P	DNG		
M Monochrom	DNG	<u>Light</u>	
M Monochrom (Typ 246)	DNG	L16	DNG
M10 Monochrom	DNG	<u>Mamiya</u>	
Q (Typ 116)	DNG	Mamiya DM22	MOS
Q2	DNG	Mamiya DM28	MOS
Q2 Monochrom	DNG	Mamiya DM33	MOS
S2	DNG	Mamiya DM56	MOS
S (Typ 007)	DNG	Mamiya M18	TIF, IIQ
S3	DNG	Mamiya M22	TIF, IIQ
SL (Typ 601)	DNG	Mamiya M31	TIF, liQ
SL2	DNG	Mamiya DM40	MOS
T (Typ 701)	DNG	ZD	MEF, MFW
TL	DNG		
TL2	DNG	<u>Nikon</u>	
V-LUX 1	RAW	1 J1	NEF
V-LUX 2	RAW	1 J2	NEF
V-LUX 3	RAW	1 J3	NEF
V-LUX 4	RAW	1 J4	NEF
V-LUX 5	RWL	1 J5	NEF
V-LUX (Typ 114)	RWL	1 S1	NEF
X2	RWL	1 S2	NEF
X (Typ 113)	DNG	1 V1	NEF
X-U (Typ 113)	DNG	1 V2	NEF
		1 V3	NEF
<u>LG</u>		COOLPIX 5000	NEF
G7 ThinQ	DNG	COOLPIX 5400	NEF
G8 ThinQ Front Camera	DNG	COOLPIX 5700	NEF
G8 ThinQ Rear Main Camera	DNG	COOLPIX 8400	NEF
		COOLPIX 8700	NEF

Nikon / contd	RAW .Extn	Nikon / contd	RAW .Extn
COOLPIX 8800	NEF	D750	NEF
COOLPIX A	NEF	D780	NEF
COOLPIX A1000	NRW	D800	NEF
COOLPIX B700	NRW	D800E	NEF
COOLPIX P330	NRW	D810	NEF
COOLPIX P340	NRW	D810A	NEF
COOLPIX P1000	NRW	D850	NEF
COOLPIX P6000	NRW	D3000	NEF
COOLPIX P7000	NRW	D3100	NEF
COOLPIX P7100	NRW	D3200	NEF
COOLPIX P7700	NRW	D3300	NEF
COOLPIX P7800	NRW	D3400	NEF
COOLPIX P950	NEF	D3500	NEF
D1	NEF	D5000	NEF
D1H	NEF	D5100	NEF
D1X	NEF	D5200	NEF
D2H	NEF	D5300	NEF
D2Hs	NEF	D5500	NEF
D2X	NEF	D5600	NEF
D2Xs	NEF	D7000	NEF
D3	NEF	D7100	NEF
D3s	NEF	D7200	NEF
D3X	NEF	D7500	NEF
D4	NEF	Df	NEF
D4S	NEF	Z 50	NEF
D5	NEF	Z 5	NEF
D40	NEF	Z 6	NEF
D40x	NEF	Z 6 II	NEF
D50	NEF	Z 7	NEF
D60	NEF	Z 7 II	NEF
D6	NEF		
D70	NEF		
D70S	NEF		
D80	NEF	<u>Nokia</u>	
D90	NEF	Lumia 1020	DNG
D100	NEF	HMD Global Nokia 9	
D200	NEF	PureView Front Camera	DNG
D300	NEF	HMD Global Nokia 9	
D300s	NEF	PureView Rear Camera	DNG
D500	NEF		
D600	NEF	<u>Openlab RAW Image</u>	OLR
D610	NEF		
D700	NEF		
D750	NEF		
D780	NEF		
D800	NEF		
D800E	NEF		
D810	NEF		
D810A	NEF		

<u>Olympus</u>	RAW .Extn	Olympus /contd	RAW .Extn
AIR A01	ORF	PEN E-PL9	ORF
Camedia C-5050 Zoom	ORF	PEN E-PM1	ORF
Camedia C-5060 Zoom	ORF	PEN E-PM2	ORF
Camedia C-7070 Wide Zoom	ORF	PEN-F	ORF
Camedia C-8080 Wide Zoom	ORF	SP-310	ORF
E-1	ORF	SP-320	ORF
E-3	ORF	SP-350	ORF
E-5	ORF	SP-500 UZ	ORF
E-10	ORF	SP-510 UZ	ORF
E-20	ORF	SP-550 UZ	ORF
E-30	ORF	SP-560 UZ	ORF
E-420	ORF	SP-565 UZ	ORF
E-450	ORF	SP-570 UZ	ORF
E-520	ORF	Stylus 1	ORF
E-600	ORF	Stylus SH-2	ORF
E-620	ORF	Stylus SH-3	ORF
EVOLT E-300	ORF	Stylus Tough TG-4	ORF
EVOLT E-330	ORF	Stylus Tough TG-5	ORF
EVOLT E-400	ORF	Stylus Tough TG-6	ORF
EVOLT E-410	ORF	Stylus XZ-2 his	ORF
EVOLT E-500	ORF	Stylus XZ-10	ORF
EVOLT E-510	ORF	XZ-1	ORF
OM-D E-M1	ORF		
OM-D E-M1X	ORF	<u>OnePlus</u>	
OM-D E-M1 Mark II	ORF	7T Front Camera	DNG
OM-D E-M1 Mark III	ORF	7T Rear Main Camera	DNG
OM-D E-M5	ORF	8 Front Camera	DNG
OM-D E-M5 Mark II	ORF	8 Rear Main Camera	DNG
OM-D E-M5 Mark III	ORF	8 Pro Front Camera	DNG
OM-D E-M10	ORF	8 Pro Rear Main Camera	DNG
OM-D E-M10 Mark II	ORF		
OM-D E-M10 Mark III	ORF	<u>Panasonic</u>	
OM-D E-M10 Mark III S	ORF	LUMIX AG-GH4	RW2
OM-D E-M10 Mark IV	ORF	LUMIX DC-FZ80(DC-FZ82, DC-FZ85)	RW2
PEN E-P1	ORF	LUMIX DC-FZ81 (DC-FZ83)	RW2
PEN E-P2	ORF	LUMIX DC-FZ1000M2 (DC-FZ10002)	RW2
PEN E-P3	ORF	LUMIX DC-G100 (DC-G110)	RW2
PEN E-P5	ORF	LUMIX DC-G9	RW2
PEN E-PL1	ORF	LUMIX DC-G99	
PEN E-PL1s	ORF	(DC-G90, DC-G91, DC-G95)	RW2
PEN E-PL10	ORF	LUMIX DC-GF9	
PEN E-PL2	ORF	(DC-GX850, DC-GX800)	RW2
PEN E-PL3	ORF	LUMIX DC-GF10 (DC-GF90)	RW2
PEN E-PL6	ORF	LUMIX DC-GH5	RW2
PEN E-PL5	ORF	LUMIX DC-GH5s	RW2
PEN E-PL7	ORF	LUMIX DC-GX880	RW2
PEN E-PL8	ORF	LUMIX DC-LX100 II	RW2
PEN E-PL9	ORF	LUMIX DC-S1	RW2
		LUMIX DC-S1H	RW2
		LUMIX DC-S1R	RW2

	RAW .Extn		RAW .Extn
Panasonic /contd		Panasonic /contd	
LUMIX DC-S5	RW2	LUMIX DMC-GM5	RW2
LUMIX DC-ZS70		LUMIX DMC-GX1	RW2
(DC-TZ90, DC-TZ91, DC-TZ92, DC-TZ93)	RW2	LUMIX DMC-GX7	RW2
LUMIX DC-ZS80		LUMIX DMC-GX8	RW2
(DC-TZ95, DC-TZ96, DC-TZ97)	RW2	LUMIX DMC-GX85	
LUMIX DMC-CM1	RW2	(DMC-GX80, DMC-GX7MK2)	RW2
LUMIX DMC-CM10	RW2	LUMIX DC-GX9 (DC-GX7MK3)	RW2
LUMIX DMC-FZ1000	RW2	LUMIX DMC-L1	RAW
LUMIX DMC-FX150	RW2	LUMIX DMC-L10	RAW
LUMIX DMC-FZ8	RAW	LUMIX DMC-LC1	RAW
LUMIX DMC-FZ18	RAW	LUMIX DMC-LF1	RW2
LUMIX DMC-FZ28	RW2	LUMIX DMC-LX1	RAW
LUMIX DMC-FZ30	RAW	LUMIX DMC-LX2	RAW
LUMIX DMC-FZ35	RW2	LUMIX DMC-LX3	RW2
LUMIX DMC-FZ38	RW2	LUMIX DMC-LX5	RW2
LUMIX DMC-FZ40 (DMC-FZ45)	RW2	LUMIX DMC-LX7	RW2
LUMIX DMC-FZ50	RAW	LUMIX DMC-LX9	
LUMIX DMC-FZ70	RW2	(DMC-LX10, DMC-LX15)	RW2
LUMIX DMC-FZ72	RW2	LUMIX DMC-LX100	RW2
LUMIX DMC-FZ100	RW2	LUMIX DMC-TZ82	RW2
LUMIX DMC-FZ150	RW2	LUMIX DMC-ZS40	
LUMIX DMC-FZ200	RW2	(DMC-TZ60, DMC-TZ61)	RW2
LUMIX DMC-FZ2500		LUMIX DMC-ZS50	
(DMC-FZ2000, DMC-FZH1)	RW2	(DMC-TZ70, DMC-TZ71)	RW2
LUMIX DMC-FZ300	RW2	LUMIX DMC-ZS60	
LUMIX DMC-FZ330	RW2	(DMC-TZ80, DMC-TZ81, DMC-TZ85)	RW2
LUMIX DMC-G1	RW2	LUMIX DMC-ZS100	
LUMIX DMC-G2	RW2	(DMC-ZS110, DMC-TZ100, DMC-TZ101,	
LUMIX DMC-G3	RW2	DMC-TZ110, DMC-TX1)	RW2
LUMIX DMC-G5	RW2	LUMIX ZS200	
LUMIX DMC-G6	RW2	(DC-TX2, DC-TZ200, DC-TZ202, DC-TZ220, DC-ZS220)	RW2
LUMIX DMC-G7	RW2		
LUMIX DMC-G8		<u>Parrot</u>	
(DMC-G80, DMC-G81, DMC-G85)	RW2	Anafi	DNG
LUMIX DMC-G10	RW2		
LUMIX DMC-GF1	RW2	<u>Pentax</u>	
LUMIX DMC-GF2	RW2	645D	DNG,
LUMIX DMC-GF3	RW2	“ ”	PEF
LUMIX DMC-GF5	RW2	645Z	DNG,
LUMIX DMC-GF6	RW2	“ “	PEF
LUMIX DMC-GF7	RW2	*ist D	PEF
LUMIX DMC-GF8	RW2	*ist DL	PEF
LUMIX DMC-GH1	RW2	*ist DL2	PEF
LUMIX DMC-GH2	RW2	*ist DS	PEF
LUMIX DMC-GH3	RW2	*ist DS2	PEF
LUMIX DMC-GH4	RW2	K-01	DNG
LUMIX DMC-GM1	RW2	K-1	DNG,
LUMIX DMC-GM1S	RW2		PEF

	RAW .Extn	Phase One /contd	RAW .Extn
Pentax /contd			
K-1 II	DNG, PEF	IQ 180 IQ 250	IIQ IIQ
K-3	DNG, PEF	IQ 260 IQ 280	IIQ IIQ
K-3 II	DNG, PEF	IQ3 50MP IQ3 60MP	IIQ IIQ
K-5	DNG, PEF	IQ3 80MP IQ3 100MP	IIQ IIQ
K-5 II	DNG, PEF	IQ3 100MP Trichromatic IQ4 150MP	IIQ IIQ
K-5 IIs	DNG, PEF	P 20 P 20+	TIF TIF
K-7	PEF	P 21	TIF
K-30	DNG	P 21+	TIF
K-50	DNG	P 25	TIF
K-70	PEF	P 25+	TIF
K-500	DNG	P 30	TIF
KP	DNG, PEF	P 30+ P 40+	TIF IIQ
K-r	PEF	P 45	TIF
K-S1	DNG, PEF	P 45+ P 65+	TIF IIQ
K-S2	DNG, PEF		
K-x	PEF	<u>Photoshop - Adobe</u>	PSD
K10D	DNG, PEF		
K20D	DNG, PEF		
K100D	PEF	<u>Ricoh</u>	
K100D Super	PEF	GR	DNG
K110D	PEF	GR II	DNG
K200D	DNG, PEF	GR III GR Digital	DNG DNG
K2000 K-m	PEF	GR Digital II	DNG
MX-1	DNG	GR Digital III	DNG
Q	DNG	GR Digital IV	DNG
Q7	DNG	GX100	DNG
Q10	DNG, PEF	GX200	DNG
QS-1	DNG	GXR with GR LENS A12 28mm F2.5 GXR with GR LENS A12 50mm F2.5 MACRO	DNG DNG
<u>Phase One</u>			
H 20	TIF	A16 24-85 F3.5-5.5	DNG
H 25	TIF	GXR with GR LENS	
IQ 140	IIQ	S10 24-72mm F2.5-4.4 VC	DNG
IQ 160	IIQ	GXR with GR LENS Mount A12	DNG
IQ 150	IIQ	THETA Z1	DNG

Samsung

EK-GN100	SRW
EK-GN110	SRW
EK-GN120	SRW
EK-KN120	SRW
EX2F	SRW
Galaxy Note 9	DNG
Galaxy Note 20 Rear Main Camera	DNG
Galaxy Note 20 Ultra Rear Main Camera	DNG
Galaxy S20 Front Camera	DNG
Galaxy S20 Rear Main Camera	DNG
Galaxy S20+ Front Camera	DNG
Galaxy S20+ Rear Main Camera	DNG
Galaxy S20 Ultra Front Camera	DNG
Galaxy S20 Ultra Rear Main Camera	DNG
Galaxy S6	DNG
Galaxy S6 Edge	DNG
Galaxy S7	DNG
Galaxy S7 Edge	DNG
Galaxy S8	DNG
Galaxy S8+	DNG
Galaxy S9	DNG
Galaxy S9+	DNG
GX-1L	PEF
GX-1S	PEF
GX-10	DNG
GX-20	DNG
NX1	SRW
NX5	SRW
NX10	SRW
NX11	SRW
NX20	SRW
NX30	SRW
NX100	SRW
NX200	SRW
NX210	SRW
NX300	SRW
NX500	SRW
NX1000	SRW
NX1100	SRW
NX2000	SRW
NX3000	SRW
NX3300	SRW
NX U	SRW
Pro 815	DNG
TL350 (WB2000)	SRW
TL500 (EX1)	SRW

RAW .Extn

Sigma

DP1	X3F
DP1s	X3F
DP2	X3F
fp	DNG
SD9	X3F
SD10	X3F
SD14	X3F

Skydio

Skydio 2	DNG
----------	-----

Sony

A7 (ILCE-7)	ARW
A7 II (ILCE-A7M2)	ARW
A7 III (ILCE-7M3)	ARW
A7C (ILCE-7C)	ARW
A7R (ILCE-7R)	ARW
A7R II (ILCE-7RM2)	ARW
A7R III (ILCE-7RM3)	ARW
A7R IV (ILCE-7RM4)	ARW
A7S (ILCE-7S)	ARW
A7S II (ILCE-7SM2)	ARW
A7s III (ILCE-7SM3)	ARW
a9 II (ILCE-9M2)	ARW
A33 (SLT-A33)	ARW
A35 (SLT-A35)	ARW
A37 (SLT-A37)	ARW
A55V (SLT-A55V)	ARW
A57 (SLT-A57)	ARW
A58 (SLT-A58)	ARW
A65 (SLT-A65)	ARW
A68 (ILCA-68)	ARW
A77 (SLT-A77)	ARW
A77 II (ILCA-77M2)	ARW
A99 (SLT-A99V)	ARW
A99 II (ILCA-99M2)	ARW
A100 (DSLR-A100)	ARW
A200 (DSLR-A200)	ARW
A230 (DSLR-A230)	ARW
A290 (DSLR-A290)	ARW
A300 (DSLR-A300)	ARW
A330 (DSLR A330)	ARW
A350 (DSLR-A350)	ARW
A380 (DSLR-A380)	ARW
A390 (DSLR-A390)	ARW
A450 (DSLR-A450)	ARW
A500 (DSLR-A500)	ARW
A550 (DSLR-A550)	ARW

RAW .Extn

Sony /contd

A560 (DSLR-A560)	ARW
A580 (DSLR-A580)	ARW
A700 (DSLR-A700)	ARW
A850 (DSLR-A850)	ARW
A900 (DSLR-A900)	ARW
A3000 (ILCE-3000)	ARW
A3500 (ILCE-3500)	ARW
A5000 (ILCE-5000)	ARW
A5100 (ILCE-5100)	ARW
A6000 (ILCE-6000)	ARW
A6100 (ILCE-6100)	ARW
A6300 (ILCE-6300)	ARW
A6400 (ILCE-6400)	ARW
A6500 (ILCE-6500)	ARW
A6600 (ILCE-6600)	ARW
DSC-F828	SRF
DSC-HX95	ARW
DSC-HX99	ARW
DSC-V3	SRF
NEX-3	ARW
NEX-3N	ARW
NEX-5	ARW
NEX-5N	ARW
NEX-5R	ARW
NEX-5T	ARW
NEX-6	ARW
NEX-7	ARW
NEX-C3	ARW
NEX-F3	ARW
NEX-VG20	ARW
NEX-VG30	ARW
NEX-VG900	ARW
RX0 (DSC-RX0)	ARW
RX0 II (DSC-RX0M2)	ARW
RX1 (DSC-RX1)	ARW
RX1R (DSC-RX1R)	ARW
RX1R II (DSC-RX1RM2)	ARW
RX10 (DSC-RX10)	ARW
RX10 II (DSC-RX10M2)	ARW
RX10 III (DSC-RX10M3)	ARW
RX10 IV (DSC-RX10M4)	ARW
RX100 (DSC-RX100)	ARW
RX100 II (DSC-RX100M2)	ARW
RX100 III (DSC-RX100M3)	ARW
RX100 IV (DSC-RX100M4)	ARW
RX100 V (DSC-RX100M5)	ARW
RX100 VA (DSC-RX100M5A)	ARW
RX100 VI (DSC-RX100M6)	ARW

RAW .Extn

Sony /contd

RX100 VII (DSC-RX100M7)	ARW
QX1 (ILCE-QX1)	ARW
ZV-1 (DCZV1/B)	ARW

Yuneec

CGO4	DNG
ION L1 Pro	DNG

Zeiss

ZX1	DNG
Microscope Image	CZI

RAW .Extn